

SOFTWARE INSTALLATION IS NOT COMPLETED YET FOR PALM, POCKET PC or WINDOWS SMARTPHONE.

We have supplied you with a CD which has an installation program on it. Insert the CD into your drive the SetUp.exe program should run automatically. Do this first, then continue with the additional steps needed.

If the CD program does not run automatically, go to your CD drive and double click on the setup.exe program.

What The CD Installation DOES Do

If you choose to use a PC for your diagnostics, this installation will copy the VitalScan software for the Car-Pal OBD Interface unit to your computer's hard drive

There is a new folder containing the software on your hard drive. This is called "**c:\program files\VitalOBD**" unless you chose differently during software installation.

What you need to do after this installation has run.

Palm Users	<p>If you are using a PALM device, read the section "Using the Car-Pal OBD Interface Unit with A Palm Device" in the main User Guide. (User Guide.pdf).</p> <p>This is in the folder "c:\program files\VitalOBD" if you used the default installation folder option. It may also be found on the installation CD, under "\Software".</p>
Pocket PC Users	<p>If you are using a Pocket PC (PDA, Windows Mobile, e.g. Acer n30) device read the section "Using the Car-Pal OBD Interface Unit with a Pocket PC" in the main User Guide. (User Guide.pdf).</p> <p>This is in the folder "c:\program files\VitalOBD" if you used the default installation folder option. It may also be found on the installation CD, under "\Software".</p>
Windows Smartphone Users	<p>If you are using a Windows Smartphone (Windows CE Phone Edition, e.g. Orange C550) device, read and follow the section "Using the Car-Pal OBD Interface unit A Windows Smartphone" in the main User Guide. (User Guide.pdf).</p> <p>This is in the "c:\program files\VitalOBD" folder if you used the default installation folder option. It may also be found on the installation CD, under "\Software".</p>

<p>Windows PC Users</p>	<p>If you are using a Windows PC and you have already got Bluetooth installed follow the main User Guide (User Guide.pdf).</p> <p>If you are using a Windows PC and you have additionally bought a Bluetooth USB device from Vital Engineering Ltd. for your PC, follow these instructions carefully:</p> <ol style="list-style-type: none"> 1) You must run an additional installation before you connect the USB Bluetooth device to your PC. This may be done EITHER from the main software installation (from the installation CD), OR manually as shown in steps 2 to 5 here. 2) Open the USB_Bluetooth folder on the CD supplied with the OBD Bluetooth Transmitter. 3) Double click on the setup.exe program to install new Bluetooth software for the USB Bluetooth device for your PC. 4) After this installation has run, connect the USB device to your PC. Choose the AUTOMATIC driver installation option, and click next. 5) When the drivers are completely installed the Bluetooth icon will change to WHITE on BLUE on your PC's desktop (in the area near the clock). <p>If you have your own Bluetooth device already set up, note the COM port to use with the Car-Pal OBD Interface Unit. You should find out how to do this from the suppliers of your Bluetooth device.</p> <p>Once this additional installation has been completed follow the main user guide (User Guide.pdf) on how to use the Windows software.</p>
---------------------------------	--

If you have problem related to the operation of the Car-Pal OBD interface unit please contact
<mailto:support@vitalengineering.co.uk>